

User Manual

PV Grid-Connected Inverter

SG110CX / SG110CX-20



All Rights Reserved

All Rights Reserved

No part of this document can be reproduced in any form or by any means without the prior written permission of Sungrow Power Supply Co., Ltd (hereinafter "SUNGROW").

Trademarks

SUNGROW.

All other trademarks or registered trademarks mentioned in this manual are owned by their respective owners.

Software Licenses

- It is prohibited to use data contained in firmware or software developed by SUNGROW, in part or in full, for commercial purposes by any means.
- It is prohibited to perform reverse engineering, cracking, or any other operations that compromise the original program design of the software developed by SUNGROW.

About This Manual

The manual mainly contains the product information, as well as guidelines for installation, operation, and maintenance. The manual does not include complete information about the photovoltaic (PV) system. Readers can get additional information at **www.sungrowpower. com** or on the webpage of the respective component manufacturer.

Validity

This manual is valid for the following model of low-power grid-connected PV string inverters:

- SG110CX
- SG110CX-20

It will be referred to as "inverter" hereinafter unless otherwise specified.

Target Group

This manual is intended for professional technicians who are responsible for installation, operation, and maintenance of inverters, and users who need to check inverter parameters. The inverter must only be installed by professional technicians. The professional technician is required to meet the following requirements:

- Know electronic, electrical wiring and mechanical expertise, and be familiar with electrical and mechanical schematics.
- Have received professional training related to the installation and commissioning of electrical equipment.
- Be able to quickly respond to hazards or emergencies that occur during installation and commissioning.
- Be familiar with local standards and relevant safety regulations of electrical systems.
- Read this manual thoroughly and understand the safety instructions related to operations.

How to Use This Manual

Please read this manual carefully before using the product and keep it properly at a place for easy access.

All contents, pictures, marks, and symbols in this manual are owned by SUNGROW. No part of this document may be reprinted by the non-internal staff of SUNGROW without written authorization.

Contents of this manual may be periodically updated or revised, and the actual product purchased shall prevail. Users can obtain the latest manual from **support.sungrowpower.com** or sales channels.

Symbols

This manual contains important safety instructions, which are highlighted with the following symbols, to ensure personal and property safety during usage, or to help optimize the product performance in an efficient way. Please carefully understand the meaning of these warning symbols to better use the manual.

DANGER

Indicates high-risk potential hazards that, if not avoided, may lead to death or serious injury.

A WARNING

Indicates moderate-risk potential hazards that, if not avoided, may lead to death or serious injury.

ACAUTION

Indicates low-risk potential hazards that, if not avoided, may lead to minor or moderate injury.

NOTICE

Indicates potential risks that, if not avoided, may lead to device malfunctions or financial losses.



"NOTE" indicates additional information, emphasized contents or tips that may be helpful, e.g., to help you solve problems or save time.

Contents

	Rights Reserved
	oout This ManualII
1	Safety Instructions1
	1.1 Unpacking and Inspection1
	1.2 Installation Safety1
	1.3 Electrical Connection Safety2
	1.4 Operation Safety
	1.5 Maintenance Safety4
	1.6 Disposal Safety4
2	Product Description
	2.1 System Introduction5
	2.2 Product Introduction
	2.3 Symbols on the Product8
	2.4 LED Indicator8
	2.5 DC Switch
	2.6 Circuit Diagram9
	2.7 Function Description10
3	Unpacking and Storage12
	3.1 Unpacking and Inspection12
	3.2 Inverter Storage12
4	Mechanical Mounting14
	4.1 Safety during Mounting14
	4.2 Location Requirements
	4.2.1 Environment Requirements15
	4.2.2 Carrier Requirements15
	4.2.3 Angle Requirements16
	4.2.4 Clearance Requirements16
	4.3 Installation Tools17
	4.4 Moving the Inverter
	4.4.1 Manual Transport19
	4.4.2 Hoisting Transport

	4.5 Installing the mounting-bracket	21
	4.5.1 PV Bracket-Mounted Installation	22
	4.5.2 Wall-Mounted Installation	23
	4.6 Installing the Inverter	24
5	Electrical Connection	25
	5.1 Safety Instructions	25
	5.2 Terminal Description	26
	5.3 Electrical Connection Overview	28
	5.4 Crimp OT / DT terminal	30
	5.5 External Grounding Connection	31
	5.5.1 External Grounding Requirements	32
	5.5.2 Connection Procedure	32
	5.6 Opening the Wiring Compartment	33
	5.7 AC Cable Connection	34
	5.7.1 AC Side Requirements	34
	5.7.2 Requirements for OT/DT Terminal	35
	5.7.3 Connection Procedure(For a multi-core cable)	36
	5.7.4 Connection Procedure(L1/L2/L3/N, For four single-core cables)	39
	5.7.5 Connection Procedure(L1/L2/L3/PE, For four single-core	
	cables)	41
	5.8 DC Cable Connection	44
	5.8.1 PV Input Configuration	45
	5.8.2 Assembling the PV Connectors	46
	5.8.3 Installing the PV Connector	47
	5.9 RS485 Connection	48
	5.9.1 Interface Description	48
	5.9.2 RS485 Communication System	49
	5.9.3 Connection Procedure(Terminal Block)	51
	5.9.4 Connection Procedure (RJ45 Ethernet Port)	52
	5.10 Dry Contact Connection	54
	5.10.1 Dry Contact Function	54
	5.10.2 Wiring Procedure	56
	5.11 DRM Connection(For Countries "AU" and "NZ")	56
	5.11.1 DRM Function	56
	5.11.2 Connection Procedure	57
	5.12 Closing the Wiring Compartment	58
	5.13 Communication Module Connection (optional)	58

Commissioning	60
6.1 Inspection before Commissioning	60
6.2 Commissioning Procedure	60
iSolarCloud App	61
7.1 Brief Introduction	61
7.2 Installing the App	61
7.3 Function Overview	62
7.4 Login	62
7.4.1 Requirements	62
7.4.2 Login Procedure	62
7.5 Home page	66
7.6 Run Information	69
7.7 Records	70
7.8 More	72
7.8.1 System Parameters	72
7.8.2 Operation Parameters	73
7.8.3 Power Regulation Parameters	75
7.8.4 Communication Parameters	80
7.8.5 Firmware Update	80
7.8.6 Password Changing	82
System Decommissioning	83
8.1 Disconnecting the Inverter	83
8.2 Dismantling the Inverter	83
8.3 Disposal of the Inverter	84
Troubleshooting and Maintenance	
9.1 Troubleshooting	85
9.2 Maintenance	93
9.2.1 Maintenance Notices	93
9.2.2 Routine Maintenance	94
9.2.3 Cleaning Air Inlet and Outlet	95
9.2.4 Fan Maintenance	95
Appendix	
-	
	6.1 Inspection before Commissioning

1 Safety Instructions

When installing, commissioning, operating, and maintaining the product, strictly observe the labels on the product and the safety requirements in the manual. Incorrect operation or work may cause:

- Injury or death to the operator or a third party.
- Damage to the product and other properties.
 - The safety instructions in this manual are only supplements and cannot cover all the precautions that should be followed. Perform operations considering actual onsite conditions.
 - SUNGROW shall not be held liable for any damage caused by violation of general safety operation requirements, general safety standards, or any safety instruction in this manual.
 - When installing, operating, and maintaining the product, comply with local laws and regulations. The safety precautions in this manual are only supplements to local laws and regulations.

1.1 Unpacking and Inspection

\Lambda WARNING

i.

Check all safety signs, warning labels and nameplates on devices. Ensure that the safety signs, warning labels and nameplates must be clearly visible and cannot be removed or covered before the device is decommissioned.

NOTICE

After receiving the product, check whether the appearance and structural parts of the device are damaged, and check whether the packing list is consistent with the actual ordered product. If there are problems with the above inspection items, do not install the device and contact SUNGROW in time.

1.2 Installation Safety

A DANGER

Make sure there is no electrical connection before installation. Before drilling, avoid the water and electricity wiring in the wall.

CAUTION

Improper installation may cause personal injury!

- If the product supports hoisting transport and is hoisted by hoisting tools, no one is allowed to stay under the product.
- When moving the product, be aware of the product weight and keep the balance to prevent it from tilting or falling.

NOTICE

Before operating the product, must check and ensure that tools to be used have been maintained regularly.

1.3 Electrical Connection Safety

DANGER

Before electrical connections, please make sure that the inverter is not damaged, otherwise it may cause danger!

Before electrical connections, please make sure that the inverter switch and all switches connected to the inverter are set to "OFF", otherwise electric shock may occur!

DANGER

The PV string will generate lethal high voltage when exposed to sunlight.

- Operators must wear proper personal protective equipment during electrical connections.
- Must ensure that cables are voltage-free with a measuring instrument before touching DC cables.
- Respect all safety instructions listed in relevant documents about PV strings.
- The inverter must not be connected to a PV string that requires positive or negative grounding.

DANGER

Danger to life due to a high voltage inside the inverter!

- Be sure to use special insulation tools during cable connections.
- Note and observe the warning labels on the product, and perform operations strictly following the safety instructions.
- Respect all safety instructions listed in this manual and other pertinent documents.

A WARNING

Damage to the product caused by incorrect wiring is not covered by the warranty.

- Electrical connection must be performed by professionals.
- All cables used in the PV generation system must be firmly attached, properly insulated, and adequately dimensioned.

A WARNING

Check the positive and negative polarity of the PV strings, and connect the PV connectors to corresponding terminals only after ensuring polarity correctness. During the installation and operation of the inverter, please ensure that the positive or negative poles of PV strings do not short-circuit to the ground. Otherwise, an AC or DC short-circuit may occur, resulting in equipment damage. The damage caused by this is not covered by the warranty.

NOTICE

Comply with the safety instructions related to PV strings and the regulations related to the local grid.

1.4 Operation Safety

DANGER

- When the inverter is running, do not touch its enclosure.
- When the inverter is running, it is strictly forbidden to plug and unplug any connector on the inverter.
- When the inverter is running, do not touch any wiring terminal of the inverter. Otherwise, electric shock may occur.
- When the inverter is running, do not disassemble any parts of the inverter. Otherwise, electric shock may occur.
- When the inverter is running, it is strictly forbidden to touch any hot parts of the inverter (such as the heat sink). Otherwise, it may cause burns.
- If the inverter is equipped with a DC switch, do not operate it when the inverter is running. Otherwise, device damage or personal injury may occur.

1.5 Maintenance Safety

DANGER

Risk of inverter damage or personal injury due to incorrect service!

- Before any service work, first disconnect the grid-side AC circuit breaker and check the inverter status. If the inverter indicator is off, please wait until night to disconnect the DC switch. If the inverter indicator is on, directly disconnect the DC switch.
- After the inverter is powered off for 5 minutes, measure the voltage and current with professional instrument. Only when there is no voltage nor current can operators who wear protective equipment operate and maintain the inverter.
- Even if the inverter is shut down, it may still be hot and cause burns. Wear protective gloves before operating the inverter after it cools down.

A DANGER

Touching the power grid or the contact points and terminals on the inverter connected to the power grid may lead to electric shock!

• The power grid side may generate voltage. Always use a standard voltmeter to ensure that there is no voltage before touching.

ACAUTION

To prevent misuse or accidents caused by unrelated personnel: Post prominent warning signs or demarcate safety warning areas around the inverter to prevent accidents caused by misuse.

NOTICE

To avoid the risk of electric shock, do not perform any other maintenance operations beyond those described in this manual. If necessary, contact your distributor first. If the problem persists, contact SUNGROW. Otherwise, the losses caused is not covered by the warranty.

1.6 Disposal Safety

A WARNING

Please scrap the product in accordance with relevant local regulations and standards to avoid property losses or casualties.

2 **Product Description**

2.1 System Introduction

The inverter is a transformerless 3-phase PV grid-connected inverter. As an integral component in the PV power system, the inverter is designed to convert the direct current power generated from the PV modules into grid-compatible AC current and to feed the AC current into the utility grid.

The intended usage of the inverter is illustrated in the following figure.




figure 2-1 Inverter Application in PV Power System

WARNING

The inverter must not be connected to a PV string that requires positive or negative grounding.


Do not connect any local load between the inverter and the AC circuit breaker.

NOTICE

The inverter applies only to the scenarios described in this manual.

Item	Description	Note	
٨	D\/ atringa	Monocrystalline silicon, polycrystalline silicon and thin-film	
A	PV strings	without grounding.	
B Inverter SG110CX/SG110CX-20			
С	Grid connection	Includes devices such as AC circuit breaker, SPD, metering	
C	cabinet	device.	
-	Transformer	Boost the low voltage from the inverter to grid-compatible me-	
D		dium voltage.	
E	Utility grid TN-C, TN-S, TN-C-S, TT, IT.		


The following figure shows the common grid configurations.



2.2 Product Introduction

Model Description

The model description is as follows(Take SG110CX-20 as an example):



Appearance

The following figure shows the appearance of the inverter. The image shown here is for reference only. The actual product received may differ.




figure 2-2 Inverter Appearance

* The image shown here is for reference only. The actual product received may differ.

No.	Name	Description	
4	LED indicator	HMI interface to indicate the present working state of the	
1	panel	inverter.	
2	Labels	Warning symbols, nameplate, and QR code.	
2	Additional ground-	2, use at least one of them to ground the inverter.	
3	ing terminals		
4	Bottom handles	2, used to move the inverter.	
5	Side handles	2, used to move the inverter.	
6	Mounting ears	4, used to hang the inverter onto the mounting-bracket.	
7		DC switches, DC terminals, and communication terminals.	
/	Wiring area	For details, refer to"5.2 Terminal Description"	

Dimensions

The following figure shows the dimensions of the inverter.




figure 2-3 Dimensions of the Inverter(in mm)

* The image shown here is for reference only. The actual product received may differ.

2.3 Symbols on the Product

Symbol	Explanation
X	Do not dispose of the inverter together with household waste.
	TÜV mark of conformity.
"	CE mark of conformity.
Ce	EU/EEA Importer.
	Regulatory compliance mark.
G	CGC-SOLAR mark of conformity.
	Danger to life due to high voltages!
<u>_</u>	Only qualified personnel can open and service the inverter.
Λ	Disconnect the inverter from all the external power sources before
	maintenance!
	Burn danger due to the hot surface that may exceed 60°C.
	Do not touch live parts for 5 minutes after disconnection from the power
5min	sources.
i	Read the user manual before maintenance!

* The table shown here is for reference only. The actual product received may differ.

2.4 LED Indicator

The LED indicator on the front of the inverter indicates the working state of the inverter.

LED color	State	Definition
	0	The device is connected to the grid and operating
	On	normally.
	Fast blink	The Bluetooth communication is connected and there
	(Period: 0.2s)	is data communication.
Blue		No system fault occurs.

table 2-1 State description of the LED indicator

LED color	State	Definition
	Slow blink (Period: 2s)	The device is in standby or startup state (not feeding power into the grid).
	On	A fault occurs and the device cannot connect to the grid.
Red	Twinkling	The Bluetooth connection is established, data commu- nication in process, and a system fault occurs.
	OFF	Both the AC and DC sides are powered down.
Gray		

A WARNING

Voltage may still be present in AC side circuits after the indicator is off. Pay attention to the electricity safety during operating.

2.5 DC Switch

The DC switch is used to disconnect the DC current safely whenever necessary. The SG110CX/SG110CX-20 is equipped with three DC switches, and each DC switch controls its corresponding DC terminals.



Turn the DC switches to the ON position before restarting the inverter.

2.6 Circuit Diagram

The following figure shows the main circuit of the inverter.




figure 2-4 Circuit Diagram

• The DC SPD provides a discharge circuit for the DC side over-voltage power to prevent it from damaging the internal circuits of the inverter.



- EMI filters can filter out the electromagnetic interference inside the inverter to ensure that the inverter meets the requirements of electromagnetic compatibility standards.
- The MPPT is utilized for DC input to ensure the maximum power from the PV array at different PV input conditions.
- The inverter circuit converts the DC power into grid-compliant AC power and feeds it into the grid.
- The AC filter filters the output AC component of high frequency to ensure that the output current meets the grid requirements.
- The AC relay isolates the AC output of the inverter from the grid, making the inverter safe from the grid in case of inverter failure or grid failure.
- The AC SPD provides a discharge circuit for the AC side over-voltage power to prevent it from damaging the internal circuits of the inverter.

2.7 Function Description

The inverter is equipped with the following functions:

Conversion Function

The inverter converts the DC current into grid-compatible AC current and feeds the AC current into the grid.

Data Storage

The inverter logs running information, error records, etc.

Parameter Configuration

The inverter provides various settable parameters. Users can set parameters via the App to meet the requirements and optimize the performance.

Communication Interface

The inverter is designed with standard RS485 communication interfaces.

The standard RS485 communication interfaces are used to establish communication connection with monitoring devices and upload monitoring data by using communication cables. After communication connection is established, users can view inverter information or set inverter parameters through the iSolarCloud.


Protection Function

The protective functions are integrated in the inverter, including anti-island protection, LVRT/ HVRT, DC reversed polarity protection, AC short circuit protection, leakage current protection, DC overvoltage/overcurrent protection, etc.


PID Recovery

The PID effect (Potential Induced Degradation) of PV modules will cause serious damage to generated output and yield, which can be avoided or recovered by PID recovery function.

• For positive voltage scheme, after the PID is enabled, the voltage to ground of all PV strings is greater than 0, and therefore the PV string-to-ground voltage is a positive value.



• For negative voltage scheme, after the PID is enabled, the voltage to ground of all PV strings is lower than 0, and therefore the PV string-to-ground voltage is a negative value.



NOTICE

- Before enabling the PID recovery function, make sure the voltage polarity of the PV modules to ground meets requirement. If there are any questions, contact the PV module manufacturer or read the corresponding user manual.
- If the voltage scheme for the PID protection / recovery function does not meet the requirement of corresponding PV modules, the PID will not work as expected or even damage the PV modules.
- PID recovery function and Q at night cannot be enabled at the same time.
- If the PID recovery function is enabled, it only works at night.
- After the PID recovery function is enabled, the voltage of the PV string to ground is 500Vdc by default, and the default value can be modified through the App.

AFCI Function(Optional)

AFCI activation

This function can be enabled to detect whether arc occurs in the DC circuit of the inverter.

AFCI self-test

This function is intended to detect whether the AFCI function of the inverter is normal.



3 Unpacking and Storage

3.1 Unpacking and Inspection

The product is thoroughly tested and strictly inspected before delivery. Nonetheless, damage may still occur during shipping. For this reason, please conduct a thorough inspection after receiving the product.

- Check the packing case for any visible damage.
- · Check the scope of delivery for completeness according to the packing list.
- Check the inner contents for damage after unpacking.

Contact SUNGROW or the transport company in case of any damage or incompleteness, and provide photos to facilitate services.

Do not dispose of the original packing case. It is recommended to store the device in the original packing case when the product is decommissioned.

NOTICE

After receiving the product, check whether the appearance and structural parts of the device are damaged, and check whether the packing list is consistent with the actual ordered product. If there are problems with the above inspection items, do not install the device and contact your distributor first. If the problem persists, contact SUNGROW in time.

If any tool is used for unpacking, be careful not to damage the product.

3.2 Inverter Storage

Proper storage is required if the inverter is not installed immediately.

- Store the inverter in the original packing case with the desiccant inside.
- The storage temperature must be always between -40°C and +70°C, and the storage relative humidity must be always between 0 and 95 %, non-condensing.
- In case of stacking storage, the number of stacking layers should never exceed the limit marked on the outer side of the packing case.
- The packing case should be upright.
- If the inverter needs to be transported again, pack it strictly before loading and transporting it.

- Do not store the inverter in places susceptible to direct sunlight, rain, and strong electric field.
- Do not place the inverter in places with items that may affect or damage the inverter.
- Store the inverter in a clean and dry place to prevent dust and water vapor from eroding.
- Do not store the inverter in places with corrosive substances or susceptible to rodents and insects.
- Carry out periodic inspections. Inspection shall be conducted at least once every six months. If any insect or rodent bites are found, replace the packaging materials in time.
- If the inverter has been stored for more than a year, inspection and testing by professionals are required before it can be put into operation.

NOTICE

Please store the inverter according to the storage requirements. Product damage caused by failure to meet the storage requirements is not covered by the warranty.

4 Mechanical Mounting

A WARNING

Respect all local standards and requirements during mechanical installation.

4.1 Safety during Mounting

DANGER

Make sure there is no electrical connection before installation. Before drilling, avoid the water and electricity wiring in the wall.

A WARNING

Poor installation environment will affect system performance!

- Install the inverter in a well-ventilated place.
- Ensure that the heat dissipation system or vent is not blocked.
- Do not install the inverter in an environment with flammable and explosive objects or smoke.


Improper handling may cause personal injury!

- When moving the inverter, be aware of its weight and keep the balance to prevent it from tilting or falling.
- Wear proper protective equipment before performing operations on the inverter.
- The bottom terminals and interfaces of the inverter cannot directly contact the ground or other supports. The inverter cannot be directly placed on the ground.

4.2 Location Requirements


Select an optimal mounting location for safe operation, long service life and expected performance.

- The inverter with protection rating IP66 can be installed both indoors and outdoors.
- Install the inverter at a place convenient for electrical connection, operation, and maintenance.



4.2.1 Environment Requirements

- The installation environment must be free of inflammable or explosive materials.
- The location should be not accessible to children.
- The ambient temperature and relative humidity must meet the following requirements.



- Do not install the inverter outdoors in areas with high salinity, which mainly refer to the areas within 500 m away from the coast. The deposition of salt fog varies largely with nearby seawater characteristics, sea wind, precipitation, relative humidity, terrain, and forest coverage.
- Inverters free from direct sunlight, direct rain and snow have longer service life. Consider sheltered places as the installation location.
- The inverter should be well ventilated. Ensure air circulation.
- The inverter generates noise during operation and is not recommended to be installed in living areas.

4.2.2 Carrier Requirements


The mounting structure where the inverter is installed must comply with local/national standards and guidelines. Ensure that the installation surface is solid enough to bear four times the weight of the inverter and is suitable for the dimensions of the inverter (e.g. cement walls, plasterboard walls, etc.).




4.2.3 Angle Requirements

Install the inverter vertically or at the maximum allowable rear tilt angle. Do not install the inverter horizontally, forward, excessively backward, sideways, or upside down.

Please consult SUNGROW before tilting backwards the inverter and install it in floating power plants.



In case the installation site is a level surface, mount the inverter to the bracket to meet the mounting angle requirements, as shown in the figure below.




Take the following items into account when designing the bracket scheme:

- Consider onsite climate conditions and take anti-snow and anti-rain measures if necessary.
- Ensure that the waterproof connectors are at least 300mm higher than the ground surface.
- Bind the cables at the positions 300~350mm away from the DC connector, AC waterproof terminal, and communication waterproof terminal.
- The various waterproof terminals should be tightened in accordance with the torque requirements in this manual to ensure that they are tight and sealed.

4.2.4 Clearance Requirements

A

Reserve enough clearance around the inverter to ensure sufficient space for heat dissipation.




* In case the distance is less than 800 mm, move the inverter from the mounting-bracket or wall before maintaining fans.

In case of multiple inverters, reserve specific clearance between the inverters. For other installation scenarios, please refer to the relevant technical documents on http://support.sungrowpower.com/.



In case of back-to-back installation, reserve specific clearance between the two inverters.



Install the inverter at an appropriate height for ease of viewing LED indicator and operating switch(es).

4.3 Installation Tools

Installation tools include but are not limited to the following recommended ones. If necessary, use other auxiliary tools on site.

```
table 4-1 Tool specification
```



SUNGROW

MC4 terminal	MC4 terminal	Multimeter	RJ45 crimping tool
crimping pliers	wrench	≥ 1100 Vdc	
4–6mm ²			
\bigcap			

Vacuum cleaner

4.4 Moving the Inverter

Before installation, remove the inverter from the packing case and move it to the installation site. Follow the instructions below as you move the inverter:

- Always be aware of the weight of the inverter.
- Lift the inverter using the handles positioned on both sides of the inverter.
- Move the inverter by one or two people or by using a proper transport tool.
- Do not release the equipment unless it has been firmly secured.

Improper handling may cause personal injury!

- Arrange an appropriate number of personnel to carry the inverter according to its weight, and installation personnel should wear protective equipment such as anti-impact shoes and gloves.
- Attention must be paid to the center of gravity of the inverter to avoid tilting during handling.
- Placing the inverter directly on a hard ground may cause damage to its metal enclosure. Protective materials such as sponge pad or foam cushion should be placed underneath the inverter.
- Move the inverter by holding the handles on it. Do not move the inverter by holding the terminals.

4.4.1 Manual Transport

step 1 Release the sealing screws on the mounting ears with a flat-head screwdriver and store them properly. Anchor the four supplied screw-in handles to the mounting ears and base of the inverter.




- step 2 Lift and move the inverter to the destination by using the side and bottom handles as well as the four installed handles.
- step 3 Remove the screw-in handles and reassemble the sealing screws released in Step 1.


- - End

4.4.2 Hoisting Transport


step 1 Release the sealing screws on the mounting ears and store them properly. Anchor two M12 thread lifting rings to the hangers of the inverter.



- step 2 Lead the sling through the two lifting rings and fasten the tie-down strap.
- step 3 Hoist the inverter, and stop to check for safety when the inverter is 100mm above the ground. Continue hoisting the device to the destination after ensuring the safety.



step 4 Remove the lifting rings and reassemble the sealing screws released in Step 1.





The lifting rings and the sling are not within the delivery scope.

- - End

4.5 Installing the mounting-bracket

Inverter is installed on the wall and bracket by means of mounting bracket. The expansion plug set shown below is recommended for the installation.






figure 4-1 Dimensions of mounting-bracket

4.5.1 PV Bracket-Mounted Installation


step 1 Assemble the mounting-bracket by using the connecting bar.



step 2 Level the assembled mounting-bracket by using the level, and mark the positions for drilling holes on the PV bracket. Drill the holes by using a hammer drill.



step 3 Secure the mounting-bracket with bolts.




No.	Components	Description
А	Mounting-bracket	_
В	Full threaded bolt	M10*45
С	Metal bracket	_
D	Flat washer	_

No.	Components	Description
E	Spring washer	_
F	Hex nuts	M10


- - End

4.5.2 Wall-Mounted Installation


step 1 Assemble the mounting-bracket by using the connecting bar.




step 2 Level the assembled mounting-bracket by using the level, and mark the positions for drilling holes on the installation site.



step 3 Insert the expansion bolts into the holes and secure them with a rubber hammer. Fasten the nut with a wrench to expand the bolt. Remove the nut, spring washer, and flat washer, and store them properly.



step 4 Fix the mounting-bracket with the expansion bolts.




No.	Components	Description
Α	Wall	-
В	Expansion bolt	Fastening the bolt in the sequence of nut, spring wash- er, slat washer
С	Mounting-bracket	-


- - End

4.6 Installing the Inverter

- step 1 Take out the inverter from the packing case.
- step 2 Hoist the inverter to the installation position when necessary (refer to ""4.4.2 Hoisting Transport""). If the installation position is not high enough, skip this step.
- step 3 Hang the inverter to the mounting-bracket and ensure that the mounting ears perfectly engage with the mounting-bracket.



step 4 Fix the inverter with screws.



- - End

5 Electrical Connection

5.1 Safety Instructions

DANGER

The PV string will generate lethal high voltage when exposed to sunlight.

- Operators must wear proper personal protective equipment during electrical connections.
- Must ensure that cables are voltage-free with a measuring instrument before touching DC cables.
- Respect all safety instructions listed in relevant documents about PV strings.

DANGER

- Before electrical connections, please make sure that the inverter switch and all switches connected to the inverter are set to "OFF", otherwise electric shock may occur!
- Ensure that the inverter is undamaged and all cables are voltage free before performing electrical work.
- Do not close the AC circuit breaker until the electrical connection is complete.

A WARNING

Damage to the product caused by incorrect wiring is not covered by the warranty.

- Electrical connection must be performed by professionals.
- Operators must wear proper personal protective equipment during electrical connections.
- All cables used in the PV generation system must be firmly attached, properly insulated, and adequately dimensioned.

NOTICE

All electrical connections must comply with local and national / regional electrical standards.

- Cables used by the user shall comply with the requirements of local laws and regulations.
- Only with the permission of the national / regional grid department, the inverter can be connected to the grid.

NOTICE


- All vacant terminals must be covered with waterproof covers to prevent affecting the protection rating.
- When the wiring is completed, seal the gap of cable inlet and outlet holes with fireproof / waterproof materials such as fireproof mud to prevent foreign matter or moisture from entering and affecting the long-term normal operation of the inverter.
- Comply with the safety instructions related to PV strings and the regulations related to the utility grid.



The cable colors in figures in this manual are for reference only. Please select cables according to local cable standards.

5.2 Terminal Description

All electrical terminals are located at the bottom of the inverter.






figure 5-1 Terminal Description(For a multi-core cable)




figure 5-2 Terminal Description(For four single-core cables)


* The image shown here is for reference only. The actual product received may differ.

Item	Terminal	Mark	Note	
А	PV terminals	+ / -	MC4 PV connector	
	Communica	COM1/2/3	RS485 communication, digital input/output DI/	
В	Communica-		DO.	
	tion terminal	COM4	For communication module connection.	
6	AC wiring		Lead for AC output cable connection	
C	terminal	_	Used for AC output cable connection.	
	Standby AC			
D grounding			Used for internal grounding.	
	terminal*			
	Additional			
Е	grounding	(上)	use at least one of them to ground the inverter.	
	terminal			

*If the PE cable is an independent single-core cable, it should be inserted into the cabinet through the standby grounding terminal.

5.3 Electrical Connection Overview

The electrical connection should be realized as follows:



Item	Designation
А	PV string
В	Inverter
С	Grid
D	Monitoring device
E	AC circuit breaker

			Specification	
No.	Cable	Туре	Cable Diame-	Cross-sectional Area
			ter(mm)	(mm²)
		PV cable comply-		
1	DC cable	ing with 1,500V	6~9	4~6
		standard		
	Additional Outdoor single- grounding core copper wire		The same as th	at of the PE wire in the AC
2			cable	
	cable	cable	Cabio	
		Four/Five-core out-		L1,L2,L3,(N) wire: 70 ~ 240
		door copper or alu-	38 ~ 56	PE wire: refer to "table 5-2
		minum cable ⁽¹⁾⁽²⁾		PE Wire Requirements"
3	AC cable	Four single-core		L1,L2,L3,(N) wire: 70 ~ 240
		outdoor copper or	14 ~ 32	PE wire: refer to "table 5-2
		aluminum cables ⁽¹⁾		PE Wire Requirements"
		Shielded twisted		
	Communi-	pair (terminal	4.5 ~ 18	0.1 ~ 1.5
4	cation	block)		
	cable	CAT-5 Ethernet ca-		
		ble (RJ45)		1

table 5-1 Cable Requirements

(1) A copper to aluminum adapter terminal is required when an aluminum cable is used. For details, refer to " Aluminium Cable Requirements".

(2) In the case of four single-core cables, a spare AC sealing plate accessory is required as shown in the following figure. To purchase the AC sealing plate accessory, contact SUNGROW.




figure 5-3 Spare AC Sealing Plate



Inverter for Australia and New Zealand are equipped with the four-core sealing plate by default.




table 3-2 FL Wire Requirements			
	PE Wire		
PE Wire Cross	Cross	Note n	
Section S	Section		
	S/2	The specifications are valid only when the phase wire	
0 > 05		and PE wire use the same material. If otherwise, ensure	
S > 35 mm ²		that the cross section of the PE wire produces a conduc-	
		tance equivalent to that of the wire specified in the table.	

table 5-2 PE Wire Requirements

5.4 Crimp OT / DT terminal

Crimp OT / DT terminal



3. Hydraulic pliers 4. Heat gun

Aluminium Cable Requirements

If an aluminium cable is selected, use a copper to aluminium adapter terminal to avoid direct contact between the copper bar and the aluminium cable.




figure 5-4 Aluminium cable terminal connection sequence

1. Copper to Aluminium adapter terminal 2. Flange nut 3. Aluminium cable

NOTICE

Ensure that the selected terminal can directly contact with the copper bar. If there are any problems, contact the terminal manufacturer.

Ensure that the copper bar is not in direct contact with the aluminum wire. Otherwise, electrochemical corrosion may occur, impairing the reliability of electrical connection.

5.5 External Grounding Connection

DANGER

Electric shock!

• Make sure that the ground cable is connected reliably. Otherwise, it may cause electric shock.

A WARNING

- Since the inverter is not equipped with a transformer, neither the negative electrode nor the positive electrode of the PV string can be grounded. Otherwise, the inverter will not operate normally.
- Connect the grounding terminal to the protective grounding point before AC cable connection, PV string connection, and communication cable connection.

A WARNING

The external protective grounding terminal must meet at least one of the following requirements.

- The cross-sectional area of the AC side grounding cable is not less than 10 mm² for copper wire or 16 mm² for aluminum wire. It is recommended that both the external protective grounding terminal and the AC side grounding terminal be reliably grounded.
- If the cross-sectional area of the AC side grounding cable is less than 10 mm² for copper wire or 16 mm² for aluminum wire, ensure that both the external protective grounding terminal and the AC side grounding terminal are reliably grounded.

The grounding connection can be made by other means if they are in accordance with the local standards and regulations, and SUNGROW shall not be held liable for the possible consequences.

5.5.1 External Grounding Requirements


All non-current carrying metal parts and device enclosures in the PV power system should be grounded, for example, brackets of PV modules and inverter enclosure.

When there is only one inverter in the PV system, connect the external grounding cable to a nearby grounding point.

When there are multiple inverters in the PV system, connect grounding points of all inverters and the PV array frames to the equipotential cable (according to the onsite conditions) to implement an equipotential connection.

5.5.2 Connection Procedure

- step 1 Prepare the cable and OT / DT terminal, refer to " Crimp OT / DT terminal".
- step 2 Remove the screw on the grounding terminal and fasten the cable with a screwdriver.



step 3 Apply paint to the grounding terminal to ensure corrosion resistance.



The grounding screws have been anchored to the side of the inverter before delivery, and do not need to be prepared.


There are two grounding terminals. Use one of them to ground the inverter.

- - End


5.6 Opening the Wiring Compartment


step 1 Release two screws on the front cover of the wiring compartment with supplied Allen wrench.

step 2 Open the wiring compartment.



step 3 Keep the wiring compartment open during wiring through the limit lever attached to the cover.





5.7 AC Cable Connection

5.7.1 AC Side Requirements



Only with the permission of the local grid department, the inverter can be connected to the grid.

Before connecting the inverter to the grid, ensure the grid voltage and frequency comply with requirements, for which, refer to **"Technical Data"**. Otherwise, contact the electric power company for help.

AC Circuit Breaker

An independent circuit breaker or fuse should be installed on the output side of the inverter to ensure safe disconnection from the grid.

Inverter Model	Recommended rated voltage	Recommended rated current
SG110CX	400V	200A
SG110CX-20	400V	200A

WARNING

AC circuit breakers should be installed on the output side of the inverter and the grid side to ensure safe disconnection from the grid.

- Determine whether an AC circuit breaker with greater overcurrent capacity is required based on actual conditions.
- Do not connect any local load between the inverter and the AC circuit breaker.
- Multiple inverters cannot share one AC circuit breaker.

Residual Current Monitoring Device

With an integrated universal current-sensitive residual current monitoring unit included, the inverter will disconnect immediately from the mains power once a fault current with a value exceeding the limit is detected.

However if an external residual current device (RCD) (type A is recommended) is mandatory, the switch must be triggered at the residual current. RCD of other specifications can also be used according to local standard. The recommended residual current is as follows.

Inverter	Recommended residual current
SG110CX	1100 mA
SG110CX-20	1100 mA

Multiple Inverters in Parallel Connection

If multiple inverters are connected in parallel to the grid, ensure that the total number of parallel inverters does not exceed 25.

MV Transformer

The MV transformer used together with the inverter should meet the following requirements:

- The transformer may be a distribution transformer, and it must be designed for the typical cyclical loads of a PV system (load in the day and no load at night).
- The transformer may be of the liquid-immersed type or dry type, and shield winding is not necessary.
- The line-to-line voltage on the LV side of the transformer should endure the output voltage of inverter. When the transformer is connected to the IT grid, to-ground withstanding voltage of the LV winding of the transformer, the LV side AC cables, and the LV side secondary equipment (including the relay protection device, detection & measuring device, and other related auxiliary devices) should not be lower than 1,100V.
- The line-to-line voltage on the HV side of the transformer should comply with the local power grid voltage.
- A transformer with a tap changer on the HV side is recommended in order to keep consistent with the grid voltage.
- At an ambient temperature of 45°C, the transformer can run in 1.1 times of load for long time.
- A transformer with a short-circuit impedance 6% (permissible tolerance: ±10%) is recommended.
- The voltage drop of system cable is no more than 3%.
- The DC component that the transformer can withstand is 1% of the fundamental current at rated power.
- For thermal rating, the load curve of the transformer and environment conditions should be taken into account.
- The apparent power of the inverter should never exceed the power of the transformer. The maximum AC current of all inverters connected in parallel must be taken into account. It is recommended that the total number of inverters that are connected to the grid not exceed 25.
- The transformer must be protected against overloading and short circuit.
- The transformer is an important part of grid-connected PV generation system. The fault tolerance capacity of the transformer should be taken into account at all times. The fault include: system short circuit, grounding fault, voltage drop, etc.
- Take ambient temperature, relative humidity, altitude, air quality, and other environmental conditions into account when selecting and installing the transformer.

5.7.2 Requirements for OT/DT Terminal

OT/DT terminals (not included in the delivery scope) are required for fixing AC cables to the terminal block. Purchase the OT/DT terminals according to the following requirements.

OT/DT Terminals of Phase Wire

• Specification: M12;

• Dimensions: a≤46 mm / 13 mm≤b≤15.5 mm / c≤22 mm



OT/DT Terminal of PE Wire


• Specification: M8 / M10.

5.7.3 Connection Procedure(For a multi-core cable)




In this manual, description is given by using five-core cable as an example. The wiring of the four-core cable is the same.


- step 1 Open the wiring compartment. For details, refer to "5.6 Opening the Wiring Compartment".
- step 2 Disconnect the AC-side circuit breaker and prevent it from inadvertent reconnection.
- step 3 Loosen the swivel nut of the AC waterproof connector and select a seal according to the cable outer diameter, remove the inner sealing ring if the cable diameter is larger than 47 mm. Lead the cable through the swivel nut, seal, and wiring terminal successively.



step 4 Remove the protection cover and store the released screws properly.




step 5 Strip the protection layer and insulation layer by specific length, as described in the figure below.




- step 6 Make the cable and crimp OT/DT terminal.
- step 7 Secure the wires to corresponding terminals.


NOTICE

Note the terminal positions of PE wire and N wire. If a phase wire is connected to the PE terminal or N terminal, unrecoverable damage may be caused to the inverter.







step 8 Gently pull the cable backwards to ensure firm connection, and fasten the swivel nut clockwise.



NOTICE




step 9 Install the protection cover




- - End

5.7.4 Connection Procedure(L1/L2/L3/N, For four single-core cables)


- step 1 Open the wiring compartment. For details, refer to"5.6 Opening the Wiring Compartment".
- step 2 Disconnect the AC-side circuit breaker and prevent it from inadvertent reconnection.
- step 3 Loosen the swivel nut of the AC waterproof connector and select a seal according to the cable outer diameter, remove the inner sealing ring if the cable diameter is larger than 22 mm. Lead the cable through the swivel nut, seal, and wiring terminal successively.



step 4 Remove the protection cover and store the released screws properly.




step 5 Strip the protection layer and insulation layer by specific length, as described in the figure below.




- step 6 Make the cable and crimp OT/DT terminal.
- step 7 Secure the wires to corresponding terminals.


NOTICE

Note the terminal positions of PE wire and N wire. If a phase wire is connected to the PE terminal or N terminal, unrecoverable damage may be caused to the inverter.






step 8 Gently pull the cable backwards to ensure firm connection, and fasten the swivel nut clockwise.




step 9 Install the protection cover




- - End

5.7.5 Connection Procedure(L1/L2/L3/PE, For four single-core cables)


- step 1 Open the wiring compartment. For details, refer to"5.6 Opening the Wiring Compartment".
- step 2 Disconnect the AC-side circuit breaker and prevent it from inadvertent reconnection.
- step 3 Loosen the swivel nut of the AC waterproof connector and select a seal according to the cable outer diameter, remove the inner sealing ring if the cable diameter is larger than 22 mm . Lead the cable through the swivel nut, seal, and wiring terminal successively.




step 4 Remove the protection cover and store the released screws properly.




step 5 Strip the protection layer and insulation layer by specific length, as described in the figure below.




- step 6 Make the cable and crimp OT/DT terminal.
- step 7 Secure the wires to corresponding terminals.






step 8 Gently pull the cable backwards to ensure firm connection, and fasten the swivel nut clockwise.



step 9 Install the protection cover



- - End

5.8 DC Cable Connection

DANGER

The PV string will generate lethal high voltage when exposed to sunlight.

Respect all safety instructions listed in relevant documents about PV strings.

WARNING

- Make sure the PV array is well insulated to ground before connecting it to the inverter.
- Make sure the maximum DC voltage and the maximum short circuit current of any string never exceed inverter permitted values specified in "Technical Data".
- Check the positive and negative polarity of the PV strings, and connect the PV connectors to corresponding terminals only after ensuring polarity correctness.
- During the installation and operation of the inverter, please ensure that the positive or negative electrodes of PV strings do not short-circuit to the ground. Otherwise, an AC or DC short-circuit may occur, resulting in equipment damage. The damage caused by this is not covered by the warranty.
- Electric arc or contactor over-temperature may occur if the PV connectors are not firmly in place, and SUNGROW shall not be held liable for any damage caused.
- If the DC input cables are reversely connected or the positive and negative terminals of different MPPT are shorted to ground at the same time, while the DC switch is in the "ON" position, do not operate immediately. Otherwise, the inverter may be damaged. Please turn the DC switch to "OFF" and remove the DC connector to adjust the polarity of the strings when the string current is lower than 0.5 A.

NOTICE

The following requirements about PV string connection must be met. Otherwise, it may cause irreversible damage to the inverter, which is not covered by the warranty.


- Mixed use of different brand or model of PV modules in one MPPT circuit, or PV modules of different orientation or angles in a string may not damage inverter but will cause system bad performance!
- The inverter enters standby state when the input voltage ranges between 1,000 V and 1,100 V. The inverter returns to running state once the voltage returns to the MPPT operating voltage range, namely, 200 V to 1,000 V.

5.8.1 PV Input Configuration

As shown in the figure below, the inverter is provided with multiple PV inputs: PV inputs 1~9; and each PV input is designed with an MPP tracker.

Each PV input operates independently and has its own MPPT. In this way, string structures of each PV input may differ from each other, including PV module type, number of PV modules in each string, angle of tilt, and installation orientation.

Each PV input area includes two DC inputs DC1 and DC2. For the best use of DC power, DC1 and DC2 should be the same in PV string structure, including the type, number, tilt, and orientation of the PV modules.



SG110CX	1100V	30A
SG110CX-	1100\/	304
20	1100V	30A

5.8.2 Assembling the PV Connectors

DANGER

High voltage may be present in the inverter!

- Ensure all cables are voltage-free before performing electrical operations.
- Do not connect the AC circuit breaker before finishing electrical connection.


ACAUTION

- Use MC4 DC terminals if the maximum input voltage is no more than 1,000 V.
- Use MC4-Evo2 DC terminals if the maximum input voltage is greater than 1,000 V. To purchase the MC4-Evo2 DC terminals, contact SUNGROW.
- Select appropriate DC terminals as required above. Otherwise, SUNGROW shall be held no liability for the damage caused.




To ensure IP66 protection, use only the supplied connector.

step 1 Strip 7 mm–8 mm of the insulation from each PV cable.



step 2 Assemble the cable ends with the crimping pliers.



2 : Negative crimp contact

step 3 Lead the cable through cable gland, and insert the crimp contact into the insulator until it snaps into place. Gently pull the cable backward to ensure firm connection. Tighten the cable gland and the insulator (torque 2.5 N.m to 3 N.m).




step 4 Check for polarity correctness.


- - End

5.8.3 Installing the PV Connector


step 1 Rotate the DC switch to "OFF" position.



step 2 Check the cable connection of the PV string for polarity correctness and ensure that the open circuit voltage in any case does not exceed the inverter input limit of 1,100V.








- step 4 Follow the foregoing steps to connect PV connectors of other PV strings.
- step 5 Seal any unused PV terminal with a terminal cap.
 - - End

5.9 RS485 Connection

5.9.1 Interface Description

The following figure shows the position of the communication wiring board as well as the terminals equipped for the wiring board.



The inverter is equipped with two groups of RS485 communication port for external communication connection, which are RS485_1 port and RS485_2 port.

The port RS485_1 is used to connect Logger, so as to implement data exchange with PC or other monitoring devices. Terminal definitions of the port are as follows:

No	Definition
A1	RS485 A IN, RS485A differential signal+
B1	RS485 B IN, RS485B differential signal-
PE	GND, shielded earthing point
A1	RS485 A OUT, RS485A differential signal+

table 5-3 RS485_1 port terminal definition (Terminal block)

No	Definition
B1	RS485 B OUT, RS485B differential signal-
PE	GND, shielded earthing point

table 5-4 RS485_1 port terminal definition (RJ45)

No	Definition
PIN1~2	N/A
PIN3	RS485 B, RS485B differential signal-
PIN4~5	N/A
PIN6	RS485 A, RS485A differential signal+
PIN7~8	N/A

The terminal block interface and RJ45 interface have the same function with different wiring manner. Select either interface for cable connection.

When multiple inverters are connected in the RS485 daisy chain, a 120Ω terminating resistor can be connected between the A and B communication cables through the RS485-dip switch, to ensure communication quality.


NOTICE

The RS485_1 interface is marked as SW1.

5.9.2 RS485 Communication System

Single-inverter Communication System

In case of a single inverter, communication cable connection requires only one RS485 cable.



Multi-inverter Communication System

In case of multiple inverters, all the inverters can be connected via RS485 cables in the daisy chain manner.




figure 5-5 Multi-inverter Communication System [RS485_1 Interface (Terminal Block)]




figure 5-6 Multi-inverter Communication System [RS485_1 Interface (RJ45)]

When more than 15 inverters are connected to the same daisy chain, in order to ensure the communication quality, the Logger at the first end of the daisy chain needs to be equipped with a terminal resistor of 120Ω , the inverter at the last end needs to be equipped with a RS485-dip switch (SW1), and the shielding layer of the communication cable should be single-point grounded.




figure 5-7 Configuration of Dip Switch (N≥15)

The length of the RS485 cable and twisted pair cable should be no longer than 1,200m.

If multiple inverters are connected to the data collector Logger3000, the number of permissible daisy chains and the number of devices allowed to be connected should meet the requirements (refer to the user manual for the Logger3000).

5.9.3 Connection Procedure(Terminal Block)

i

1


RS485 communication cables should be shielded twisted pair cables or shielded twisted pair Ethernet cables.

There are three communication terminals, and the silkscreen marks are COM1/ COM2/COM3. Please choose according to the actual situation.

step 1 Strip the protection layer and insulation layer by appropriate length.




step 2 Loosen the swivel nut of the junction box and select an appropriate seal according to cable outer diameter. Lead the cable through the swivel nut, seal, and junction box successively.




Outer Diameter D(mm)	Seal
4.5~6	c
6~12	a + b
12 ~ 18	b

step 3 Secure the cable to the terminal base.



- step 4 Insert the terminal base into the corresponding terminal.
- step 5 Pull the cable gently to make sure it is secured, tighten the swivel nut clockwise.




- - End

5.9.4 Connection Procedure (RJ45 Ethernet Port)


step 1 Loosen the swivel nut of the junction box and select an appropriate seal according to cable outer diameter. Lead the cable through the swivel nut, seal, and junction box successively.

Outer Diameter D(mm)	Seal
4.5~6	C
6 ~ 12	a+b
12 ~ 18	b


step 2 Strip the insulation layer of the Ethernet cable with a wire stripper, and insert the signal wires to the RJ45 connector(Pin 3 and Pin 6 are for communication connection). Crimp the RJ45 connector with a crimping tool.



step 3 Insert the RJ45 connector to the RJ45 jack.



step 4 Pull the cable gently to make sure it is secured, tighten the swivel nut clockwise.



- - End

5.10 Dry Contact Connection


NOTICE

Dry contact cables require a cross section of 1 mm² to 1.5 mm². The connection procedure of the dry contact is the same as that of the RS485 terminal block.

5.10.1 Dry Contact Function

The configuration circuit board is provided with fault output dry contact and emergency stop dry contact, as shown in the figure below.

Connection method of the dry contacts is similar to that of the RS485 terminal block.



Emergency stop dry contact Fault output dry contact

DO terminal (fault output dry contact): The relay can be set to output fault alarms, and user can configure it to be a normally open contact (COM & NO) or a normally closed contact (COM & NC).

The relay is initially at the NC terminal, and it will trip to another contact when a fault occurs. When alarm occurs, signal status change will not be triggered.

Use LED indicators or other equipment to indicate whether the inverter is in the faulty state. The following Figures show the typical applications of normally open contact and normally closed contact:




figure 5-8 Normal open contact




figure 5-9 Normal close contact

Devices connected to the relay should comply with related requirements:

AC-Side Requirements	DC-Side Requirements
Max. voltage: 125Vac	Max. voltage: 30Vdc
Max. current: 5A	Max. current: 5A

DI terminal (emergency stop dry contact): the dry contact can be configured to be an emergency stop contact. Use either of the following methods for configuration.

Method 1 : When the DI + contact and DI-contact are shorted by external controlled switch (The external switch can be configured as normally open contact or normally closed contact), the inverter will immediately shutdown.

Method 2 : Passive Valid can be set. When Passive Valid is enabled on the iSolarCloud, the inverters will operate normally when DI + contact and DI-contact are shorted by external controlled switch, and the inverters will emergently stop when DI + contact and DI- contact are disconnected.



The dry contacts only support passive switch signal input.

The following figure shows the typical application of local stop dry contact.






figure 5-11 Daisy chain topology

When wiring DI dry contacts, ensure that the maximum wiring distance meet the requirements in "10.2 Wring Distance of DI Dry Contact".


5.10.2 Wiring Procedure

Refer to the wiring of terminal block described in chapter"5.9.3 Connection Procedure(Terminal Block)" to implement fault output, emergency shutdown. For emergency shutdown(passive valid), enable the function on iSolarCloud, refer to "7.8.2 Operation Parameters".

5.11 DRM Connection (For Countries "AU" and "NZ")

5.11.1 DRM Function

The inverter supports the demand response modes as specified in the standard AS/NZS 4777. The inverter has integrated a terminal for connecting to a DRED. After the connection, the method of asserting DRMs as specified in the follow table.



The mode DRM0 is supported by the inverter.



table 5-5 Method of Asserting DRMs


Mode	Method of Asserting
DRM0	Asserted by shorting pins 5 and 6
	Asserted when the impedance between pins 5 and 6 is detected to be
	above 20 kΩ

Enable the DRM function through the iSolarCloud App. If there are any problems, contact your distributor first. If the problem persists, contact SUNGROW. The DRM function is only applicable to devices for Australia and New Zealand.

5.11.2 Connection Procedure


Ť

step 1 Strip the insulation layer of the Ethernet cable with a wire stripper, and insert the signal wires to the RJ45 connector. Crimp the RJ45 connector with a crimping tool.




Pin	Assignment for inverters capable of both charging and discharging
1	DRM 1/5
2	DRM 2/6
3	DRM 3/7
4	DRM 4/8
5	RefGen
6	Com/DRM0
7	V+
8	V-

step 2 Loosen the swivel nut and select an appropriate seal according to cable outer diameter. Lead the cable through the swivel nut, and seal successively.



Outer Diameter D (mm)	Seal
4.5 ~ 6	С
6~12	a+b
13 ~ 18	b

step 3 Insert the RJ45 connector to the RJ45 jack.




step 4 Pull the cable gently to make sure it is secured, tighten the swivel nut clockwise.


- - End

5.12 Closing the Wiring Compartment

step 1 Release the limit lever.



step 2 Close the wiring compartment and tighten the two screws on its front cover with supplied Allen wrench.



- - End

5.13 Communication Module Connection (optional)

Connect the communication module produced by SUNGROW to the communication accessory port. After successful connection, information such as power generation and running state of the inverter can be viewed via the APP on the phone.



*The image shown here is for reference only. The actual product you receive may differ.

NOTICE

Once the communication module is in use, do not connect the inverter to a 3rd party data logger at the same time via RS485.

0

For details on module installation and configuration, refer to the manual delivered together with the module.

6 Commissioning

6.1 Inspection before Commissioning

Check the following items before starting the inverter:

- All equipment has been reliably installed.
- DC switch(es) and AC circuit breaker are in the "OFF" position.
- The ground cable is properly and reliably connected.
- The AC cable is properly and reliably connected.
- · The DC cable is properly and reliably connected.
- The communication cable is properly and reliably connected.
- The vacant terminals are sealed.
- No foreign items, such as tools, are left on the top of the machine or in the junction box (if there is).
- The AC circuit breaker is selected in accordance with the requirements of this manual and local standards.
- All warning signs & labels are intact and legible.

6.2 Commissioning Procedure

If all of the items mentioned above meet the requirements, proceed as follows to start up the inverter for the first time.

- step 1 Connect the AC circuit breaker between the inverter and the grid.
- step 2 Rotate the DC switch of the inverter to "ON" position.
- step 3 Connect the DC switch (if applicable) between the inverter and the PV string.
- step 4 Set initial protection parameters via the iSolarCloud App. For details, please refer to "7.2 Installing the App", and "7.4.2 Login Procedure". If the irradiation and grid conditions meet requirements, the inverter will normally operate.
- step 5 Observe the LED indicator to ensure that the inverter operates normally. Refer to "2.4 LED Indicator" for details.

- - End

7 iSolarCloud App

7.1 Brief Introduction

The iSolarCloud App can establish communication connection to the inverter via the Bluetooth, thereby achieving near-end maintenance on the inverter. Users can use the App to view basic information, alarms, and events, set parameters, or download logs, etc. *In case the communication module Eye, WiFi or WiNet-S is available, the iSolarCloud App can also establish communication connection to the inverter via the mobile data or WiFi, thereby achieving remote maintenance on the inverter.

- This manual describes only how to achieve near-end maintenance via the Bluetooth connection. For remote maintenance through the Eye, WiFi or WiNet-S, refer to the related manuals in the delivery scope.
- Screenshots in this manual are based on the Android system V2.1.6, and the actual interfaces may differ.

7.2 Installing the App

Method 1

i

Download and install the App through the following application stores:

- MyApp (Android, mainland China users)
- Google Play (Android, users other than mainland China ones)
- App Store (iOS)

Method 2

Scan the following QR code to download and install the App according to the prompt information.



The App icon appears on the home screen after installation.





7.3 Function Overview

The App provides parameter viewing and setting functions, as shown in the following figure.




figure 7-1 App function tree map

7.4 Login

7.4.1 Requirements

The following requirements should be met:


- The AC or DC side of the inverter is powered-on.
- The mobile phone is within 5 meters away from the inverter and there are no obstructions in between.
- The Bluetooth function of the mobile phone is enabled.

6

The inverter can only pair with one phone at a time through Bluetooth.

7.4.2 Login Procedure

- step 1 Open the App to enter the login page, tap **Local Access** at the bottom of the page to go to the next page.
- step 2 Scan the QR code on the side of the inverter for Bluetooth connection. Or tap **MANUAL CONNECTION** at the bottom of the interface and select **Others**, the Bluetooth search interface will automatically appear. Select the inverter to be connected according to the serial number on the nameplate on the side of the inverter, or tap



side of the inverter for Bluetooth connection. The connection is successfully established if the LED indicator blinks blue.

figure 7-2 Bluetooth Connection

step 3 Enter the identity verification screen after the Bluetooth connection is established.

f

	✓ B2210504867 🛔
Account	
user	
Password	
	ንተኛ
🛃 Remember Me	



The Account is "user", and the initial password is "pw1111" or "111111" which should be changed for the consideration of account security.

To set inverter parameters related to grid protection and grid support, contact your distributor to obtain the advanced account and corresponding password. If the distributor is unable to provide the required information, contact SUNGROW.

step 4 If the inverter is not initialized, you will enter the quick setting screen of initializing protection parameter.




figure 7-4 Initialization Protection Parameter

NOTICE

The Country/Region must be set to the country where the inverter is installed at. Otherwise, the inverter may report errors. i

In the European region, such as Sweden, Ireland, Hungary, Portugal, Romania, Greece, Ukraine etc. whose grid code complies with EN50549, select the parameter EN50549_1 (LV grid- connection) or EN50549_2 (MV grid-connection) with proper manual settings.

In the Brazilian region, set the country code as "Brazil". Selecting "Brazil_230" or "Brazil_240" will cause setting failure.

step 5 When the country is set to Australia, additionally set the applicable network service provider and then the grid type. Tap **Power Company** to select the correct power company.




figure 7-5 Initialization Power Company

The image shown here is for reference only. Refer to the actual interface for the supported network service providers.

table 7-1 Power	Company	Information
-----------------	---------	-------------

Network Service Provider	Grid Type
AS/NZS 4777.2:2015	/
AS/NZS 4777.2:2020 Australia A	/
AS/NZS 4777.2:2020 Australia B	/
AS/NZS 4777.2:2020 Australia C	/
ENERGEX & Ergon Energy	• STNW1170: single phase < 10 kVA & three phase < 30 kVA
	• STNW1174 :30 kVA < PN ≤ 1500 kVA
Endeavour Energy	MDI 0043
Ausgrid	NS194
Jemena	 ≤ 10kVA per phase (or 30 kVA per three phase) ELE GU 0014: 30-200kVA

Network Service Provider	Grid Type
CitiPower & Powercor	 ≤ 5 kVA for single-phase & 30 kVA for three-phase
	 > 30 kVA three-phase
United Energy	 UE-ST-2008.1: ≤ 10 kW for single- phase & 30 kW for three-phase
	• UE-ST-2008.2: > 30 kVA three-phase
PowerWater	Embedded Generation Notice Photovoltaic
	Systems:2020
SA Power Networks	 TS129-2019: < 10 kW for single-phase & 30 kW for three-phase
	• TS130-2017: > 30 kW & ≤ 200 kW
	• TS131-2018: > 200 kW
Horizon Power	 HPC-9DJ-13-0001-2019: ≤ 10 kVA for single-phase & 30 kVA for three-phase
	• HPC-9DJ-13-0002-2019: > 30 kVA & ≤1 MVA
westernpower	EDM # 33612889-2019
AusNet Services	Basic Micro Embedded Generation:2020

For compliance with AS/NZS 4777.2:2020, please select from Australia A/B/C. Please contact your electricity grid operator for which region to use.

- step 6 After finishing the settings, tap **TUNR ON DEVICE** at the upper right corner and the device will be initialized. The App will send start instructions and the device will start and operate.
- step 7 If the inverter is initialized, the App automatically turns to its home page.

- - End

7.5 Home page

After login, the home page is as follows:




figure 7-6 Home Page

table 7-2 Home Page Description

No.	Designation	Description
1	Date and time	System date and time of the inverter.
2 Inverter state	Present operation state of the inverter. For details, refer to	
	"table 7-3 Description of Inverter State".	
3 PID state	Present state of the PID. For details, refer to "table 7-4 De-	
	scription of PID State".	
4 Power flow chart	Displays the PV power generation power, feed-in power,	
	etc. The line with an arrow indicates energy flow between	
	connected devices, and the arrow pointing indicates energy	
	flow direction.	
5	5 Power generation	Today power yield and accumulative power yield of the
	inverter.	
6	Real-time power	Output power of the inverter.
	Shows the change of power between 5 am and 11 pm every	
7	D	day
7 1	Power curve	(Each point on the curve represents the percentage of
		present inverter power to rated power).
8	Navigation bar	Including "Home", "Run-info", "His-record", and "More".

State	Description
	After being energized, the inverter tracks the PV arrays' maximum power
Run	point (MPP) and converts the DC power into AC power. This is the nor-
	mal operation mode.
Stop	The inverter is stopped.
	The inverter will stop operation by manually "stop" via app. In this way,
Press to Shut	inverter internal DSP stops. To restart the inverter, manually start via
Down	app.
Standby	Inverter enters standby mode when DC side input is insufficient. In this
	mode the inverter will wait within the standby duration.
Initial standby	The inverter is in the initial power-on standby state.
Starting Up	The inverter is initializing and synchronizing with the grid.
Warn Run	Warning information is detected.
Derating	The inverter derates actively due to environmental factors such as tem-
running	perature or altitude
Dispatch	The inverter runs according to the scheduling instructions received from
Running	the monitoring background
Fault	If a fault occurs, the inverter will automatically stop operation, and dis-
	connect the AC relay. The fault information will be displayed in the app.
	Once the fault is removed in recovery time, the inverter will automatically
	resume running.When the country setup is German HV, which is com-
	plied with VDE-AR-4120, the inverter will not be automatically connected
	to the grid after the fault is cleared, and needs to wait for an external sig-
	nal to trigger reconnection.

table 7-3 Description of Inverter State

table 7-4 Description of PID State

State	Description	
PID recovery	The inverters perform PID recovery actively.	
running		
PID abnormity	It is detected that the ISO impedance is abnormal or the PID cannot	
	work normally after the PID being enabled.	

If the inverter is running abnormally, the alarm or fault icon will be displayed in the lower right corner of the inverter icon in power flow chart. The user can tap this icon to enter the alarm or fault screen to view detailed information and corrective measures.

7.6 Run Information

Tap **Run Information** on the navigation bar to enter the screen showing running information, slide the screen upwards to view all detailed information.

Classifica- tion	Parameter	Description
PV	String n Voltage	The input voltage of the n th string
Information	String n current	The input current of the n th string
	Total On-grid Run- ning Time	1
	Daily On-grid Run- ning Time	1
	Negative Voltage to Ground	Inverter DC side negative to ground voltage value
	Bus Voltage	Voltage between the positive and negative poles
Inverter		of the DC side of the inverter
Information	Internal Air Temperature	1
	Array Insulation	Insulation resistance value of the input side to the
	Resistance	protection ground
	Country Information	1
	Power Limitation	1
	Mode	·
	Reactive Power	1
	Mode Total DC Power	DC side total input power
Input	MPPT x Voltage	The input voltage of the x th MPPT
mpar	MPPT x Current	The input current of the x th MPPT
	Daily Yield	
	Monthly Yield	1
	Annual Yield	·
	Total Active Power	Current active power value of the inverter
	Total Reactive Power	Current reactive power value of the inverter
Output	Total Apparent	
	Power	Current apparent power value of the inverter
	Total Power Factor	Power factor of the AC side of the inverter
	Gird Frenquency	Frequency of the AC side of the inverter
	A-B Line Voltage	Line Voltage

table 7-5 Run Information

Classifica- tion	Parameter	Description
	B-C Line Voltage	
	C-A Line Voltage	_
	Phase A Current	_
	Phase B Current	Phase Current
	Phase C Current	

7.7 Records

Tap **Records** on the navigation bar to enter the screen showing event records, as shown in the following figure.

	RECORDS	*
⚠	Fault Alarm Record	>
\$	Yield Record	>
	Event Records	>

figure 7-7 Records

Fault Alarm Record

Tap Fault Alarm Record to enter the screen, as shown in the following figure.



figure 7-8 Fault Alarm Record



Click 🛅 to select a time segment and view corresponding records.

The inverter can record up to 400 latest entries.

Select one of the records in the list and click the record, to view the detailed fault info as shown in following figure.

< BACK	
GRID POWER OUTAGE	
Alarm Level: Important	
Occurrence Time: 2020-05-06 10:23:32	
Alarm ID: 10	
Repair Advice	
Generally, the device is reconnected to the grid after the grid recovers to normal. If the fault occurs repeatedly: 1.Check if the grid power supply is normal; 2.Check if AC cables are all firmly connected. 3.Check if AC cables are connected to the correct terminals (with or without live line and reverse connection). 4.If the fault still exists, Please contact customer service center of sungrow power.	

figure 7-9 Detailed Fault Alarm Information

Yield Record

Tap **Yield Record** to enter the screen showing daily power generation , as shown in the following figure.




figure 7-10 Power Curve

The App displays power generation records in a variety of forms, including daily power generation graph, monthly power generation histogram, annual power generation histogram and total power generation histogram.

table 7-6 Explanation of Power Yields Records

Parameter	Description
Power curve	Shows the power output from 5 am to 11 pm in a single day. Each point on the curve is the percentage of present power to rated power.
Daily energy histogram	Shows the power output every day in the present month.

Parameter	Description	
Monthly energy	Shows the power output every month in a year.	
histogram	chows the power output every month in a year.	
Annual energy	Shows the power output every year.	
histogram	Shows the power output every year.	

Tap the time bar on the top of the screen to select a time segment and view the corresponding power curve.

Swipe left to check the power yields histogram.

Event Record

Tap Event Record to view event record list.



Click to select a time segment and view corresponding records.

The inverter can at most record the latest 400 events.

7.8 More

Tap **More** on the navigation bar to enter the corresponding screen, as shown in the following figure.



figure 7-11 More

7.8.1 System Parameters

Tap **Settings**→**System Parameters** to enter the corresponding screen, as shown in the following figure.

< BACK
SYSTEM PARAMETERS
Boot Shutdown Boot
Date Setting 2021-11-11
Time Setting 14:19:04
Software Version 1
Software Version 2

figure 7-12 System Parameters

* The image shown here is for reference only.

Boot/Shutdown

Tap **Boot/Shutdown** to send the boot/shutdown instruction to the inverter.

For Australia and New Zealand, when the DRM state is DRM0, the "Boot" option will be prohibited.

Date Setting/Time Setting

The correct system time is very important. Wrong system time will directly affect the data logging and power generation value. The clock is in 24-hour format.

Software Version

Version information of the current firmware.

7.8.2 Operation Parameters

Running Time

Tap **Settings** \rightarrow **Operation Parameters** \rightarrow **Running Time** to enter the corresponding screen, on which you can set "Running Time".

< BACK	
RUNNING TIME	
Connecting Time 20 s	
Reconnecting Time 20 s	

figure 7-13 Running Time

PID Parameters

Tap **Settings** \rightarrow **Operation Parameters** \rightarrow **PID Parameters** to enter the corresponding screen, on which you can set "PID Parameters".

< BACK	
PID PARAMETERS	
PID Recovery	
Clear PID Alarm	
PID Scheme Apply Positive Voltage	

figure 7-14 PID Setting

table 7-7 PID Parameter Description

Parameter	Description
	Set enabling/disabling of the PID night recovery function. PID night
PID Recovery	recovery function operates between 22:00 pm and 5:00 am by
	default.
	If ISO impedance abnormality or PID function exception is de-
	tected during running of the PID function, the inverter reports a
Clear PID alarm	PID false alarm and reminds the user to take corresponding meas-
	ures. After processing, clear the alarm via this parameter.
PID Scheme	Apply negative or positive voltage.



After the PID night recovery function is enabled, the fault indicator on the inverter front panel turns green.

AFCI Parameters(Optional)

Tap Settings \rightarrow Operation Parameters \rightarrow AFCI Parameters to enter the corresponding screen, on which you can set AFCI Parameters.

< BACK	
AFCI PARAMETERS	
AFCI Self-test	
AFCI Activation On	
Clear AFCI Alarm	

figure 7-15 AFCI Setting

NS Protection (Passive Valid)

Tap Settings \rightarrow Operation Parameters \rightarrow Regular Parameters to enter the corresponding screen, on which you can set the NS Protection(Passive Valid).

< BACK	
REGULAR PARAMETERS	
NS Protection(Passive Valid)	

figure 7-16 NS Protection(Passive Valid)

7.8.3 Power Regulation Parameters

Active Power Regulation

Tap Settings \rightarrow Power Regulation Parameters \rightarrow Active Power Regulation to enter the screen, as shown in the following figure.

< back	
ACTIVE POWER REGULATION	
Active Power Soft Start after Fault	\bigcirc
Active Power Soft Start Time after Fault 60 s	
Active Power Gradient Control	\bigcirc
Active Power Decline Gradient	
Active Power Rising Gradient	
Active Power Setting Persistence	\bigcirc
Active Power Limit	
Active Power Limit Ratio	
Shutdown When Active Power Limit to 0%	
100% Scheduling to Achieve Active Overload	0

figure 7-17 Active Power Regulation

table 7-8 Active Power Regulation

Parameter	Definition/Setting Description	Range
Active power soft start after fault	The switch for enabling/dis- abling the soft start function after a fault occurs.	Enable/Disable
Active power soft start time after fault	Time that the soft start takes to raise the power from 0 to 100% rated power.	1s~1200s
Active power gradient control	Switch for enabling/disabling the active power rate settable function.	Enable/Disable
Active power decline gradient	The decline rate of inverter ac- tive power per minute.	3%/min~6000%/min

Parameter	Definition/Setting Description	Range
Active power rising gradient	The rise rate of inverter active power per minute.	3%/min~6000%/min
Active power setting persistence	Switch for enabling/disabling the function of saving output limited power.	Enable/Disable
Active power limit	The switch for limiting output power.	Enable/Disable
Active power limit ratio	The ratio of limiting output power to rated power in percentage.	0%~110%
Shutdown when active power limit to 0%	Switch used to determine whether the inverter is in stop state when the limited power reaches 0.	Enable/Disable

Reactive Power Regulation

Tap Settings \rightarrow Power Regulation Parameters \rightarrow Reactive Power Regulation to enter the screen, as shown in the following figure.

< back	
REACTIVE POWER REGULATIO	N
Reactive Power Generation at Night	
Reactive Power Ratio at Night	
Reactive Power Setting Persistence	
Closed-loop Control Reactive Power Regulation	
Reactive Power Regulation Mode	
PF 1.000	
Reactive Power Ratio	

figure 7-18 Reactive Power Regulation

Parameter	Definition/Setting Description	Range
Reactive power genera- tion at night	Switch for enabling/disabling Q at night function.	Enable/Disable
Reactive power ratio at night	Reactive power ratio set for the Q at night function.	-100%~0%/ 0%~100%
Reactive power setting Switch for enabling/disabling Enable/Disa persistence the power-off function during reactive power.		Enable/Disable
Reactive power regula- tion mode	_	Off/PF/Qt/Q(P)/Q(U)
Reactive power regulation	Switch for enabling/disabling reactive response function.	Enable/Disable
Reactive power regula- tion time	Ends time of reactive response.	0.1s~600.0s
Q(P)Curve	Select corresponding curve according to local regulations	Curve A/Curve B/Curve C*
QP_P1	Output power at P1 on the Q (P) mode curve (in percentage)	10.0%~100.0%
QP_P2	Output power at P2 on the Q (P) mode curve (in percentage)	20.0%~100.0%

Parameter	Definition/Setting Description	Range
QP_P3	Output power at P3 on the Q (P) mode curve (in percentage)	20.0%~100.0%
QP_K1	Power factor at P1 on the Q(P) mode curve	Curve A/Curve C:0.800~1.000 Curve B: [-0.600~0.600]*Ac- tive Overload Rate/1000
mode curve 0.80 Cur		Curve A/Curve C: 0.800~1.000 Curve B: [-0.600~0.600]*Ac- tive Overload Rate/1000
QP_K3	Power factor at P3 on the Q(P) mode curve	Curve A/Curve C: 0.800~1.000 Curve B: [-0.600~0.600]*Ac- tive Overload Rate/1000
QP_EnterVoltage	Voltage percentage for Q(P) function activation	100.0%~110.0%
QP_ExitVoltage	Voltage percentage for Q(P) function deactivation	90.0%~100.0%
QP_EXitPower	Power percentage for Q(P) function deactivation	1.0%-20.0%
QP_EnableMode	Unconditional activation/deac- tivation of Q(P) function	Yes/No
Q(U)Curve	Select the corresponding curve according to local regulations	Curve A/Curve B/Curve C*
QU_V1	Pre-set grid voltage U1 that is reactive according to the grid voltage	80.0%~100.0%
QU_Q1	Pre-set proportion of reactive power according to the grid voltage U1	[-60.0%-0]* Overload Rate/ 1000

Parameter	Definition/Setting Description	Range
QU_V2	Pre-set grid voltage U2 that is reactive according to the grid voltage.	80.0%~100.0%
QU_Q2	Pre-set proportion of reactive power according to the grid voltage U2.	[-60.0%-60.0%]* Overload Rate/1000
QU_V3	U_V3 Pre-set grid voltage U3 that is 100.0%~120.0% reactive according to the grid voltage.	
QU_Q3	Pre-set proportion of reactive power according to the grid voltage U3.	[-60.0%-60.0%]* Overload Rate/1000
QU_V4	Pre-set grid voltage U4 that is reactive according to the grid voltage.	100.0%~120.0%
QU_Q4	Pre-set proportion of reactive power according to the grid voltage U4.	[0-60.0%]* Overload Rate/ 1000
QU_EnterPower	Active power for Q(U) function activation	20.0%~100.0%
QU_EXitPower	Active power for Q(U) function deactivation	1.0%~20.0%
QU_EnableMode	Unconditional activation/deac- tivation of Q(U) function	Yes/No/Yes,Limited by PF
QU_Limited PF Value	_	0-0.95

**Curve C is reserved and consistent with Curve A currently.




figure 7-20 Q(P) Curve

7.8.4 Communication Parameters

Tap **Settings** \rightarrow **Communication Parameters** to enter the corresponding screen, as shown in the following figure. The device address ranges from 1 to 246.

< BACK		< BACK
COMMUNICATION PARAMETERS		SERIAL PORT PARAMETERS
Serial Port Parameters		Device Address 1



7.8.5 Firmware Update

To avoid download failure due to poor on-site network signal, it is recommended to download the firmware package to the mobile device in advance.

Perform firmware update only during high irradiance conditions in order to prevent equipment failure.

- step 1 Enable the "Mobile data" of the mobile device.
- step 2 Open the App, enter the account and password on the login screen. Tap **Login** to enter the home screen.
- step 3 Tap **More**→**Firmware Download** to enter corresponding screen on which you can view the device list.

step 4 Select the device model before downloading the firmware. Tap the device name in the de-

vice list to enter the firmware upgrade package detail interface, and tap $\stackrel{\checkmark}{\rightharpoonup}$ behind the firmware upgrade package to download it.

< back	<u> </u>
SG110CX	
Inverter	
Once the download is complete, select the dow upgrade package to upgrade through "Local Ac More/Firmware Update">>	
Sg110cx_20210519.zip	<u> </u>

- step 5 Return to the **Firmware Download** screen, tap $\underline{\checkmark}$ in the upper right corner of the screen to view the downloaded firmware upgrade package.
- step 6 Login the App via local access mode. Refer to "7.4 Login".
- step 7 Tap More on the App home screen and then tap Firmware Update.
- step 8 Tap the upgrade package file, a prompt box will pop up asking you to upgrade the firmware with the file, tap **CONFIRM** to perform the firmware upgrade.

SELECT FIRMWARE
Downloaded file
Sg110cx_20210519.zip
SG110CX

step 9 Wait for the file to be uploaded. When the upgrade is finished, the interface will inform you of the upgrade completion. Tap **Complete** to end the upgrade.



- - End

7.8.6 Password Changing

Tap **Modify Password** to enter the modify password screen, as shown in the following figure.

MODIFY PASSWORD			
	Enter a new password. Setting this password will overwrite the previous password.		
The password shall consist letters and numbers.	The password shall consist of 8-20 digits, including letters and numbers.		
user	user		
	× ****		
Confirm			

figure 7-22 Change Password

The password shall consisit of 8–20 digits, including letters and numbers.

8 System Decommissioning

8.1 Disconnecting the Inverter

Danger of burns!

Even if the inverter is shut down, it may still be hot and cause burns. Wear protective gloves before operating the inverter after it cools down.

For maintenance or other service work, the inverter must be switched off. Proceed as follows to disconnect the inverter from the AC and DC power sources. Lethal voltages or damage to the inverter will follow if otherwise.

- step 1 Disconnect the external AC circuit breaker and secure it against reconnection.
- step 2 Rotate the DC switch to the "OFF" position for disconnecting all of the PV string inputs.
- step 3 Wait about 5 minutes until the capacitors inside the inverter completely discharge.
- step 4 Ensure that the DC cable is current-free via a current clamp.

- - End

i.

8.2 Dismantling the Inverter

Risk of burn injuries and electric shock!


After the inverter is powered off for 5 minutes, measure the voltage and current with professional instrument. Only when there is no voltage nor current can operators who wear protective equipment operate and maintain the inverter.

Before dismantling the inverter, disconnect both AC and DC connections.

If there are more than two layers of inverter DC terminals, dismantle the outer DC connectors before dismantling the inner ones.

step 1 Refer to "5 Electrical Connection", for the inverter disconnection of all cables in reverse steps. In particular, when removing the DC connector, use an MC4 wrench to loosen the locking parts and install waterproof plugs.





- step 2 Refer to"4 Mechanical Mounting", to dismantle the inverter in reverse steps.
- step 3 If necessary, remove the wall-mounting bracket from the wall.
- step 4 If the inverter will be used again in the future, please refer to "3.2 Inverter Storage" for a proper conservation.

- - End

8.3 Disposal of the Inverter

Users take the responsibility for the disposal of the inverter.

WARNING

Please scrap the inverter in accordance with relevant local regulations and standards to avoid property losses or casualties.

NOTICE

Some parts of the inverter may cause environmental pollution. Please dispose of them in accordance with the disposal regulations for electronic waste applicable at the installation site.

9 Troubleshooting and Maintenance

9.1 Troubleshooting

Once the inverter fails, the fault information can be displayed on the App interface. If the inverter is equipped with an LCD screen, the fault information can be viewed on it. The fault codes and troubleshooting methods of all PV inverters are detailed in the table below. The device you purchase may only contain some of the fault information, and when the inverter fails, you can check the corresponding information through the fault codes from the mobile app.

Fault code	Fault name	Corrective measures
		Generally, the inverter will be reconnected to the
		grid after the grid returns to normal. If the fault oc-
		curs repeatedly:
		1. Measure the actual grid voltage, and contact
		the local electric power company for solutions if
0 0 14 15	Crid Overveltage	the grid voltage is higher than the set value.
2, 3, 14, 15	Grid Overvoltage	2. Check whether the protection parameters are
		appropriately set via the App or the LCD. Modify
		the overvoltage protection values with the con-
		sent of the local electric power operator.
		3. Contact Sungrow Customer Service if the pre-
		ceding causes are ruled out and the fault persists.
		Generally, the inverter will be reconnected to the
	Grid Undervoltage	grid after the grid returns to normal. If the fault oc-
		curs repeatedly:
		1. Measure the actual grid voltage, and contact
		the local electric power company for solutions if
4, 5		the grid voltage is lower than the set value.
		2. Check whether the protection parameters are
		appropriately set via the App or the LCD.
		3. Check whether the AC cable is firmly in place.
		4. Contact Sungrow Customer Service if the pre-
		ceding causes are ruled out and the fault persists.

Fault code	Fault name	Corrective measures
	Grid	Generally, the inverter will be reconnected to the
8	Overfrequency	grid after the grid returns to normal. If the fault oc-
		curs repeatedly:
		1. Measure the actual grid frequency, and contact
		the local electric power company for solutions if
9	Grid	the grid frequency is beyond the set range.
5	Underfrequency	2. Check whether the protection parameters are
		appropriately set via the App or the LCD.
		3. Contact Sungrow Customer Service if the pre-
		ceding causes are ruled out and the fault persists.
		Generally, the inverter will be reconnected to the
		grid after the grid returns to normal. If the fault oc-
		curs repeatedly:
		1. Check whether the grid supplies power reliably.
		2. Check whether the AC cable is firmly in place.
10	Grid Power	3. Check whether the AC cable is connected to
	Outage	the correct terminal (whether the live wire and
		the N wire are correctly in place).
		4. Check whether the AC circuit breaker is
		connected.
		5. Contact Sungrow Customer Service if the pre-
		ceding causes are ruled out and the fault persists. 1. The fault can be caused by poor sunlight or
		damp environment, and generally the inverter will
		be reconnected to the grid after the environment
	Excess Leakage	is improved.
12	Current	2. If the environment is normal, check whether
		the AC and DC cables are well insulated.
		3. Contact Sungrow Customer Service if the pre-
		ceding causes are ruled out and the fault persists.
13		Generally, the inverter will be reconnected to the
		grid after the grid returns to normal. If the fault oc-
		curs repeatedly:
	Grid Abnormal	1. Measure the actual grid, and contact the local
10	Grid Adnormal	electric power company for solutions if the grid
		parameter exceeds the set range.
		2. Contact Sungrow Customer Service if the pre-
		ceding causes are ruled out and the fault persists.

Fault code	Fault name	Corrective measures
17		Generally, the inverter will be reconnected to the grid after the grid returns to normal. If the fault oc- curs repeatedly:
	Grid Voltage	1. Measure the actual grid voltage. If grid phase voltages differ greatly, contact the electric power company for solutions.
	Imbalance	2. If the voltage difference between phases is within the permissible range of the local power company, modify the grid voltage imbalance pa- rameter through the App or the LCD.
		3. Contact Sungrow Customer Service if the pre- ceding causes are ruled out and the fault persists.
28, 29, 208, 212, 448-479		1. Check whether the corresponding string is of reverse polarity. If so, disconnect the DC switch and adjust the polarity when the string current drops below 0.5 A.
	PV Reserve Con- nection Fault	2. Contact Sungrow Customer Service if the pre- ceding causes are ruled out and the fault persists.
		*The code 28 to code 29 are corresponding to PV1 to PV2 respectively.
		*The code 448 to code 479 are corresponding to string 1 to string 32 respectively.
532-547, 564- 579		1. Check whether the corresponding string is of reverse polarity. If so, disconnect the DC switch and adjust the polarity when the string current drops below 0.5 A.
	PV Reverse Con- nection Alarm	2. Contact Sungrow Customer Service if the pre- ceding causes are ruled out and the alarm persists.
		*The code 532 to code 547 are corresponding to
		string 1 to string 16 respectively.
		*The code 564 to code 579 are corresponding to string 17 to string 32 respectively.

Fault code	Fault name	Corrective measures
		Check whether the voltage and current of the in-
		verter is abnormal to determine the cause of the
		alarm.
		1. Check whether the corresponding module is
		sheltered. If so, remove the shelter and ensure
		module cleanness.
		2. Check whether the battery board wiring is
		loose, if so, make it reliably connected.
548-563, 580- 595	PV Abnormal Alarm	3. Check if the DC fuse is damaged. If so, replace
595	Aldini	the fuse.
		4. Contact Sungrow Customer Service if the pre-
		ceding causes are ruled out and the alarm
		persists.
		*The code 548 to code 563 are corresponding to
		string 1 to string 16 respectively.
		*The code 580 to code 595 are corresponding to
		string 17 to string 32 respectively.
		Generally, the inverter will resume operation
		when the internal or module temperature returns
		to normal. If the fault persists:
		1. Check whether the ambient temperature of the
	Evenneively Lieb	inverter is too high;
		2. Check whether the inverter is in a well-venti-
37	Excessively High Ambient	lated place;
37	Temperature	3. Check whether the inverter is exposed to di-
		rect sunlight. Shield it if so;
		4. Check whether the fan is running properly. Re-
		place the fan if not;
		5. Contact Sungrow Power Customer Service if
		the fault is due to other causes and the fault
		persists.
	Excessively Low	Stop and disconnect the inverter. Restart the in-
43	Ambient	verter when the ambient temperature rises within
	Temperature	the operation temperature range.

Fault code	Fault name	Corrective measures
		Wait for the inverter to return to normal. If the
		fault occurs repeatedly:
		1. Check whether the ISO resistance protection
		value is excessively high via the app or the LCD,
		and ensure that it complies with the local
		regulations.
		2. Check the resistance to ground of the string
		and DC cable. Take corrective measures in case
	Low System Insu-	of short circuit or damaged insulation layer.
39	lation Resistance	3. If the cable is normal and the fault occurs on
		rainy days, check it again when the weather turns
		fine.
		4. If there are batteries, check whether battery
		cables are damaged and whether terminals are
		loose or in poor contact. If so, replace the dam-
		aged cable and secure terminals to ensure a reli-
		able connection.
		5. Contact Sungrow Customer Service if the pre-
		ceding causes are ruled out and the fault persists
		 Check whether the AC cable is correctly connected.
	Grounding Cable Fault	2. Check whether the insulation between the
106		ground cable and the live wire is normal.
	Fault	-
		 Contact Sungrow Customer Service if the pre- ceding causes are ruled out and the fault persists
		1. Disconnect the DC power supply, and check
	Electric Arc Fault	whether any DC cable is damaged, the connec-
		tion terminal or fuse is loose or there is a weak
		contact. If so, replace the damaged cable, fasten
		the terminal or fuse, and replace the burnt
88		component.
		2. After performing step 1, reconnect the DC
		power supply, and clear the electric arc fault via
		the App or the LCD, after that the inverter will re-
		turn to normal.
		3. Contact Sungrow Customer Service if the fault
		persists.

Fault code	Fault name	Corrective measures
		1. Check if the meter is wrongly connected.
	Reverse Connec-	2. Check if the input and output wiring of the me-
84	tion Alarm of the	ter is reversed.
•	Meter/CT	3. If the existing system is enabled, please check
		if the rated power setting of the existing inverter
		is correct.
		1. Check whether the communication cable and
		the terminals are abnormal. If so, correct them to
	Meter Communi-	ensure reliable connection.
514	cation Abnormal	2. Reconnect the communication cable of the
514	Alarm	meter.
		3. Contact Sungrow Customer Service if the pre-
		ceding causes are ruled out and the alarm
		persists.
	Grid Confrontation	1. Check whether the output port is connected to
202		actual grid. Disconnect it from the grid if so.
323		2. Contact Sungrow Customer Service if the pre-
		ceding causes are ruled out and the fault persists.
		1. Check whether the communication cable and
		the terminals are abnormal. If so, correct them to
75	Inverter Parallel Communication Alarm	ensure reliable connection.
		2. Reconnect the communication cable of the
		meter.
		3. Contact Sungrow Customer Service if the pre-
		ceding causes are ruled out and the alarm
		persists.

Fault code	Fault name	Corrective measures
7, 11, 16, 19–		
25, 30–34, 36,		
38, 40–42, 44–		
50, 52–58, 60–		
69, 85, 87, 92,		1. Wait for the inverter to return to normal.
93, 100–105,		2. Disconnect the AC and DC switches, and dis-
107–114, 116–		connect the battery side switches if there are bat-
124, 200–211,	System Fault	teries. Close the AC and DC switches in turn 15
248–255, 300–	System r aut	minutes later and restart the system.
322, 324–328,		,
401–412, 600–		3. Contact Sungrow Customer Service if the pre-
603, 605, 608,		ceding causes are ruled out and the fault persists.
612, 616, 620,		
622–624, 800,		
802, 804, 807,		
1096–1122		
59, 70–74, 76,		1. The inverter can continue running.
82, 83, 89, 77–	System Alarm	2. Check whether the related wiring and terminal
81, 216–218,		are abnormal, check whether there are any for-
220–232, 432–		eign materials or other environmental abnormal-
434, 500–513,	Oystem Alarm	ities, and take corresponding corrective
515–518, 635–		measures when necessary.
638, 900, 901,		3. If the fault persists, please contact Sungrow
910, 911, 996		Power Customer Service.
		1. Check whether the corresponding string is of
		reverse polarity. If so, disconnect the DC switch
		and adjust the polarity when the string current
	MPPT Reverse	drops below 0.5 A.
264-283	Connection	2. Contact Sungrow Customer Service if the pre-
		ceding causes are ruled out and the fault persists.
		*The code 264 to code 279 are corresponding to
		string 1 to string 20 respectively.

SUNGROW

Fault code	Fault name	Corrective measures
332-363		1. The inverter can continue running.
		2. Check whether the related wiring and termi-
		nals are abnormal, check whether there are any
	Boost Capacitor	foreign materials or other environmental abnor-
332-303	Overvoltage Alarm	malities, and take corresponding corrective
		measures when necessary.
		If the fault persists, please contact Sungrow
		Power Customer Service.
		1. Disconnect the AC and DC switches, and dis-
		connect the battery side switches if there are bat-
364-395	Boost Capacitor	teries. Close the AC and DC switches in turn 15
304-393	Overvoltage Fault	minutes later and restart the system.
		2. If the fault persists, please contact Sungrow
		Power Customer Service.
		1. Check whether the number of PV modules of
		the corresponding string is less than other strings.
		If so, disconnect the DC switch and adjust the PV
		module configuration when the string current
		drops below 0.5 A.
1548-1579	String Current	2. Check whether the PV module is shaded;
1548-1579	Reflux	3. Disconnect the DC switch to check whether
		the open circuit voltage is normal when the string
		current drops below 0.5 A. If so, check the wiring
		and configuration of the PV module,
		4. Check whether the orientation of the PV mod-
		ule is abnormal.

Fault code	Fault name	Corrective measures
		1. When the fault occurs, it is forbidden to directly
		disconnect the DC switch and unplug PV termi-
	PV Grounding Fault	nals when the direct current is greater than 0.5 A;
		2. Wait until the direct current of the inverter falls
1000 1015		below 0.5 A, then disconnect the DC switch and
1600 - 1615, 1632 - 1655		unplug the faulty strings;
1032 - 1055		3. Do not reinsert the faulty strings before the
		grounding fault is cleared;
		4. If the fault is not caused by the foregoing rea-
		sons and still exists, contact Sungrow Customer
		Service.
	System Hardware Fault	1. It is prohibited to disconnect the DC switch
		when the DC current is greater than 0.5 A when
		the fault occurs.
1616		2. Disconnect the DC switch only when the inver-
		ter DC side current drops below 0.5 A.
		3. It is prohibited to power up the inverter again.
		Please contact Sungrow Customer Service.

9.2 Maintenance

9.2.1 Maintenance Notices

ADANGER

Risk of inverter damage or personal injury due to incorrect service!

- Be sure to use special insulation tools when perform high-voltage operations.
- Before any service work, first disconnect the grid-side AC circuit breaker and check the inverter status. If the inverter indicator is off, please wait until night to disconnect the DC switch. If the inverter indicator is on, directly disconnect the DC switch.
- Turn the DC switch from ON to OFF and continue to turn it 20 degrees counterclockwise, the DC switch can be locked here. (For countries "AU" and "NZ")
- After the inverter is powered off for 5 minutes, measure the voltage and current with professional instrument. Only when there is no voltage nor current can operators who wear protective equipment operate and maintain the inverter
- Even if the inverter is shut down, it may still be hot and cause burns. Wear protective gloves before operating the inverter after it cools down.

ACAUTION

To prevent misuse or accidents caused by unrelated personnel: Post prominent warning signs or demarcate safety warning areas around the inverter to prevent accidents caused by misuse.

NOTICE

Restart the inverter only after removing the fault that impairs safety performance. As the inverter contains no component parts that can be maintained, never open the enclosure, or replace any internal components.

To avoid the risk of electric shock, do not perform any other maintenance operations beyond this manual. If necessary, contact SUNGROW for maintenance. Otherwise, the losses caused is not covered by the warranty.

NOTICE

Touching the PCB or other static sensitive components may cause damage to the device.

- Do not touch the circuit board unnecessarily.
- Observe the regulations to protect against electrostatic and wear an anti-static wrist strap.

Item	Method	Period	
	Check the temperature and dust of		
	the inverter. Clean the inverter enclo-	Six months to a year (de-	
System aloon	sure if necessary.		
System clean	Check if the air inlet and outlet are		
	normal. Clean the air inlet and outlet,	in air.)	
	if necessary.		
	Check whether there is fan warning		
	using App.		
F	Check whether there is any abnormal		
Fans	noise when the fan is turning.	Once a year	
	Clean or replace the fans if necessary		
	(see the following section).		

9.2.2 Routine Maintenance

Item	Method	Period
	Check whether the cable entry is in-	
Cable antra	sufficiently sealed or the gap is exces-	0
Cable entry	sively large, and reseal the entry	
	when necessary.	
	Check whether all cable are firmly	
Electrical	connected in place.	
Electrical	Check whether a cable is damaged,	Six months to a year
Connection	especially the part contacting the met-	
	al enclosure.	

9.2.3 Cleaning Air Inlet and Outlet

A significant amount of heat is generated when the inverter is working.

In order to maintain good ventilation, please check to make sure the air inlet and outlet are not blocked.

Clean the air inlet and outlet with soft brush or vacuum cleaner if necessary.


9.2.4 Fan Maintenance

A DANGER


- Power off the inverter and disconnect it from all power supplies before maintaining fans.
- After the inverter is powered off for 5 minutes, measure the voltage and current with professional instrument. Only when there is no voltage nor current can operators who wear protective equipment operate and maintain the inverter.
- Fan maintenance must be performed by professionals.

Fans inside the inverter are used to cool the inverter during operation. If the fans do not operate normally, the inverter may not be cooled down and inverter efficiency may decrease. Therefore, it is necessary to clean dirty fans and replace the broken fans in a timely manner. The operation procedure is as follows:


- step 1 Stop the inverter (see 8.1 Disconnecting the Inverter).
- step 2 Loosen the screw on the sealing plate of the fan module.



step 3 Press the tab of the latch hook, unplug the cable connection joint outwards, and loosen the screw on the fan holder.



step 4 Pull out the fan module, clean the fans with soft brush or vacuum cleaner, and replace them when necessary.



- step 5 Reinstall the fan back to the inverter in reverse order and restart the inverter.
 - - End

10 Appendix

10.1 Technical Data

Parameters	SG110CX
Input (DC)	
Recommended max. PV input power	147 kW
Max. PV input voltage	1100 V*
Min.PV input voltage/Start-up input voltage	200 V / 250 V
Nominal input voltage	585 V
MPP voltage range	200 – 1000 V
No. of independent MPP inputs	9
No. of PV strings per MPPT	2
Max DV input ourrent	234 A (26 A / 26
Max. PV input current	A / 26 A / 26 A / 26 A)
Max. DC short-circuit current	360 A (40 A / 40
	A / 40 A / 40 A / 40 A)
Output (AC)	
Max. AC Output power	110 kVA
Rated AC output apparent power	100 kVA (110 kVA for "AU")
Max. AC output current	158.8 A
Nominal AC voltage	3/N/PE, 400 V
AC voltage range	320 – 460 V
Nominal grid frequency / Grid frequency	50 Hz / 45 – 55 Hz
range	60 Hz / 55 – 65 Hz
Harmonic (THD)	< 3 % (at rated power)
Power factor at nominal power / Adjustable	>0.99 / 0.8 leading – 0.8 lagging
power factor	
Feed-in phases / AC connection	3 / 3–PE
Efficiency	
Max. efficiency / European efficiency	98.7% / 98.5%
Protection and Function	
DC reverse polarity protection	Yes
AC short circuit protection	Yes
Leakage current protection	Yes
Grid monitoring	Yes

Parameters	SG110CX
Ground fault monitoring	Yes
DC switch	Yes
AC switch	No
PV string monitoring	Yes
Q at night function	Yes
PID recovery function	Yes
DC terminal protective cover	Yes(Only for "AU")
Communication dongle (EyeM4)	Yes(Only for "AU")
Surge protection	DC Type II / AC Type II
General Data	
Dimensions (W*H*D)	1051 * 660 * 362.5 mm
Weight	89 kg
Тороlоду	Transformerless
Ingress protection rating	IP66
Night power consumption	< 2 W
Operating ambient temperature range	-30 to 60 °C (> 50 °C derating)
Allowable relative humidity range	0–100%
Cooling method	Smart forced air cooling
Max. operating altitude	4000 m (> 3000 m derating)
Display	LED, Bluetooth + APP
Communication	RS485/ Optional: WLAN, Ethernet
DC connection type	MC4 (Max. 6 mm ²)
AC connection type	OT or DT terminal (Max.240 mm ²)
	Q at night function, LVRT, HVRT, active &
Grid Support	reactive power control and power ramp rate
	control
Country of manufacture	China

* The inverter enters the standby state when the input voltage ranges between 1,000V and 1,100V. If the maximum DC voltage in the system can exceed 1000V, the MC4 connectors included in the scope of delivery must not be used. In this case MC4 Evo2 connectors must be used.

Parameters	SG110CX-20	
Input (DC)		
Max. PV input voltage	1100 V *	
Min. PV input voltage / Start-up input voltage	200 V / 250 V	

Parameters	SG110CX-20
Nominal PV input voltage	585 V
MPP voltage range	200 – 1000 V
No. of independent MPP inputs	9
No. of PV strings per MPPT	2
Max. PV input current	27 A * 9
Max. DC short-circuit current	40 A * 9
Output (AC)	
AC output power	110 kVA @ 45 °C / 100 kVA @ 50 °C
Max. AC output current	158.8 A
Nominal AC voltage	3 / N / PE, 400 V
AC voltage range	320 – 460V
Nominal grid frequency / Grid frequency range	50 Hz / 45 – 55 Hz, 60 Hz / 55 – 65 Hz
Harmonic (THD)	< 3 % (at nominal power)
Power factor at nominal power / Adjustable power factor	0.99 / 0.8 leading – 0.8 lagging
Feed-in phases / AC connection	3 / 3-PE
Efficiency	
Max. efficiency	98.7%
European efficiency	98.5%
Protection and Function	
DC reverse polarity protection	Yes
AC short circuit protection	Yes
Leakage current protection	Yes
Grid monitoring	Yes
Ground fault monitoring	Yes
DC switch	Yes
AC switch	No
PV string monitoring	Yes
Q at night function	Yes

Parameters	SG110CX-20
PID recovery function	Yes
Arc fault circuit interrupter (AFCI)	Yes
Surge protection	DC Type I + II / AC Type II
General Data	
Dimensions (W*H*D)	1051*660*362.5 mm
Weight	89 kg
Topology	Transformerless
Degree of protection	IP66
Night power consumption	< 2 W
Operating ambient temperature range	-30 to 60 °C (> 50 °C derating)
Allowable relative humidity range	0 – 100 %
Cooling method	Smart forced air cooling
Max. operating altitude	4000 m (> 3000 m derating)
Display	LED, Bluetooth+APP
Communication	RS485 / Optional: WLAN, Ethernet
DC connection type	MC4 (Max. 6 mm²)
AC connection type	OT / DT terminal (Max. 240 mm²)
Grid Support	Q at night function, LVRT, HVRT,active & reactive power control and power ramp rate control

* The inverter enters the standby state when the input voltage ranges between 1,000V and 1,100V. If the maximum DC voltage in the system can exceed 1000V, the MC4 connectors included in the scope of delivery must not be used. In this case MC4 Evo2 connectors must be used.

10.2 Wring Distance of DI Dry Contact

The maximum wiring distance of DC dry contact must meet the requirements in the Table below. The wiring distance L is the total length of all DI signal cables.

$$L = 2\sum_{k=1}^{n} L_k$$

 L_K refers to the cable length in one direction between the DI dry contact terminal of the kth inverter and the corresponding terminal of the (k-1)th inverter.

Number of	Maximum wiring distance(unit:m)	
inverter	16AWG / 1.31mm ²	17AWG / 1.026mm ²
1	13030	10552
2	6515	5276
3	4343	3517
4	3258	2638
5	2606	2110
6	2172	1759
7	1861	1507
8	1629	1319
9	1448	1172
10	1303	1055
11	1185	959
12	1086	879
13	1002	812
14	931	754
15	869	703
16	814	660
17	766	621
18	724	586
19	686	555
20	652	528
21	620	502
22	592	480
23	567	459
24	543	440
25	521	422

table 10-1 Correspondence between number of inverters and maximum wiring distance

NOTICE

In case the specification of the cable used is not included in the Table above, when there is only one inverter, ensure that the line impedance of the input node is less than 300Ω ; and when there are multiple inverters connected in the daisy chain, ensure that the impedance is less than 300Ω /number of inverter.

10.3 Quality Assurance

When product faults occur during the warranty period, SUNGROW will provide free service or replace the product with a new one.

Evidence

During the warranty period, the customer shall provide the product purchase invoice and date. In addition, the trademark on the product shall be undamaged and legible. Otherwise, SUNGROW has the right to refuse to honor the quality guarantee.

Conditions

- After replacement, unqualified products shall be processed by SUNGROW.
- The customer shall give SUNGROW a reasonable period to repair the faulty device.

Exclusion of Liability

In the following circumstances, SUNGROW has the right to refuse to honor the quality guarantee:

- The free warranty period for the whole machine/components has expired.
- · The device is damaged during transport.
- · The device is incorrectly installed, refitted, or used.
- The device operates in harsh conditions beyond those described in this manual.
- The fault or damage is caused by installation, repairs, modification, or disassembly performed by a service provider or personnel not from SUNGROW.
- The fault or damage is caused by the use of non-standard or non-SUNGROW components or software.
- The installation and use range are beyond stipulations of relevant international standards.
- The damage is caused by unexpected natural factors.

For faulty products in any of above cases, if the customer requests maintenance, paid maintenance service may be provided based on the judgment of SUNGROW.

10.4 Contact Information

In case of questions about this product, please contact us.



We need the following information to provide you the best assistance:

- Model of the device
- Serial number of the device
- Fault code/name
- Brief description of the problem

For detailed contact information, please visit: https://en.sungrowpower.com/contactUS.

